

Key information for builders and cablers



Supply internal and external conduit paths:

- Use rigid white nominal P20 telecommunications conduits (23mm Internal Diameter) in the trench (connecting to the service drop conduit) and within the house. Glue all joints using solvent cement
- Ensure the conduits run as straight as possible
- · Install drawstrings in both conduits
- Fix all conduits securely using conduit saddles or similar
- Provide a power point (GPO)
 within 1500mm of the nbn™ connection
 box location
- Each bend radius of the street conduit must be no less than 300mm
- Each bend radius of the internal conduit must be no less than 100mm
- Use no more than 3 x 90° (max) bends between draw points

Minimum **nbn**™ utility box separations:

Minimum 250mm from services including:


- Electricity, gas* or water meter enclosures
- Water taps or downpipes


Minimum 1.5m side clearance from gas cylinders*

*Check with your local Authorities for their separations

nbn to supply:

- The P20 service drop conduit from pit to 1 meter inside the property
- The service drop cable to the nbn[™] utility box location
- The **nbn**™ utility box
- The internal fibre optic cable from the nbn" utility box to the nbn" connection box
- The nbn[™] connection box
- nbn[™] connection box with battery backup power supply unit (if required during pre-installation)
- · All the fibre optic cables








If the NTD is to be enclosed, then ventilation is required for safety reasons. Refer to nbn™ Residential Preparation and Installation Guide: SDUs and MDUs for specifications.

nbn™ supplied equipment installed within the home - wall space reservations



Layout example only.
For other configurations refer to the nbn™
Residential Preparation and Installation Guide:

SDUs and MDUs.

- † For indoor installation only. nbn* supplied equipment should not be installed in prohibited locations, such as bathrooms, laundry etc. as per nbn-NO-GDE-0011 Guides
- † Builders should always provision space and environment for PS/B. It may be pre-installed or requested by the end user during the life of the building.

*Also known as Premises Connection Device ^Also known as Network Termination Device

Preparing new developments for the nbn™ network

It's important that builders and cablers talk to new homeowners about the telecommunications services they may want to access in their homes and provide guidance on where **nbn**[™] supplied equipment, phone and data outlets should be located.

Both fixed line internet and telephone services will be delivered over the **nbn**™ network. **nbn**™ supplied equipment should be located in a safe location, where it is convenient to connect the telephone as well as computers and internet TV.

It's important to remember that if customers want to utilise applications like IPTV via Smart TVs in their living room and telework via HD video conferencing in their office they should consider fixed cabling in the home to connect these devices.

Requesting equipment pre-installation

To enable a smooth and efficient connection to the **nbn**[™] network, builders/developers may request a pre-installation of the supplied equipment supporting **nbn**[™] network on behalf of all owners/occupiers of the premises.

Pre-installation of the **nbn**™ network supplied equipment should be arranged to take place at least 20 days ahead of the estimated home completion date.

To request a pre-installation of **nbn**™ supplied equipment, visit: **nbn.com.au/preinstallrequest**

The following information will be required when submitting a request:

- Confirmation that you have authority of all owners and occupiers to make this request
- Confirmation that you have the agreement of all owners and occupiers to waive their right to be given notice by the nbn[™] of the pre-installation under Schedule 3 of the Telecommunications Act 1997

- Premises address or addresses
- Developer estate name and stage number
- Confirmation that power is available
- Date by which the premises will be at secure 'lock up' stage
- Estimated completion or handover date
- An onsite contact and confirmation that you have their permission to submit their contact details
- Confirmation that an Internal and Lead-in Conduit has been installed in accordance with nbn™ guidelines
- Confirmation whether Power Supply with Battery Backup will or will not be required
- Preferred installation date

For more information

1800 687 626 newdevelopments@nbn.com.au nbn.com.au/newdevelopments

July 2015

© 2015 nbn co ltd. '**nbn**', 'bring it on', and the Aurora device are trade marks of nbn co ltd | ABN 86 136 533 741 Builder Cabler Key Information | NBN768_NewDevs_0715

Unmaintained copy. For most recent version, refer to: nbn.com.au/content/dam/nbnco/documents/key-information-for-builders-and-cablers.pdf For more details and installation options refer to: nbn^{tot} Residential Preparation and Installation Guide: SDUs and MDUs nbn.com.au/assets/documents/preparation-and-installation-guide-for-sdus-and-mdus.pdf

This document is subject to copyright and must not be used except as permitted below or under the Copyright Act 1968 (Cth). You must not reproduce or publish this document in whole or in part for commercial gain without the prior written consent of nbn co. You may reproduce and publish this document in whole or in part for educational or non-commercial purposes as approved by nbn co in writing. This document is intended as an informational guide only. nbn co does not warrant that the processes and information outlined in this document comply with all (or any) applicable laws, codes of practice or standards. The recipient must exercise its own judgement as to how best to perform the activities described in this document in a safe way, and so as to meet the requirements of all applicable laws, codes of practice and standards. The contents of this document should not be relied upon as representing any nbn co's final position on the subject matter of this document, except where stated otherwise.